

EPS SSR-2a
POWER BUS LOSS: RPCM N1RS2 A

ACTION	EQUIP/FUNCTION LOST	CREW INDICATIONS	NOTES
<p>If during Node 1 Pre-Ingress Warm-up, Ingress, or Post Egress Dryout, √MCC-H for heater configuration.</p> <div style="margin-left: 40px;">Node 1: TCS NODE 1: TCS</div> <div style="margin-left: 40px;">‘NODE 1’</div> <div style="margin-left: 40px;">sel Node 1 Htr [X] A</div> <div style="margin-left: 80px;">[X] = 123456 789</div> <div style="margin-left: 40px;">cmd Ena Opr Execute</div> <div style="margin-left: 40px;">Repeat</div>	<p>RPCM N1RS2 A (Type V)</p> <p>1 Node1 Shell Htrs String B</p>	<p><u>Caution Messages:</u></p> <p><u>Advisory Messages:</u> RPCM N1RS2 A Loss Of Comm - NOD1</p> <p><u>Telemetry:</u> PCS Node 1: EPS <div style="margin-left: 100px;">NODE 1: EPS</div></p> <p>RPCM N1RS2 A - not Active</p>	<p>① String B of the Node 1 and PMA 1 Shell Heaters are nominally primary.</p> <p>② Since the internal Early Comm equipment is lost, the entire Early Comm system is lost. Power to the Port and Stbd antennas is removed.</p> <p>③ Normally the CBMs are powered off.</p>
<p>2 Node1: EPS: RPCM: N1RS1 <div style="margin-left: 40px;">RPCM NIRS1 C</div> <div style="margin-left: 40px;">sel RPCM Detail sel RPC [X],</div> <div style="margin-left: 80px;">[X] = 5 12</div> <div style="margin-left: 40px;">cmd Open Execute</div> <div style="margin-left: 40px;">Repeat</div> </p>	<p>2 CBM N1 Stbd Pri 1 (Early Comm Transceiver Pwr & Htr) 3 CBM N1 Stbd Pri 2 (Early Comm Spare) CBM N1 Stbd Pri 3 (Early Comm CTP) CBM N1 Stbd Pri 4 (Early Comm RFPDB)</p>		
<p>On MCC GO Perform RPCM Remove and Replace Procedure (SODF: OSO)</p>			